

Crack Filling & Touch-Up Process



1. Clean Out Cracks



2. – Fill Cracks with Acrylic Patch Mix, Sand Smooth



3. Mask off 6" – 12" wide on both sides of cracks. Paint over crack and remove tape.

Crack Filling & Touch-Up Process



The result is the cleanest looking crack repair possible without a full resurfacing of the court, and as playable of a repair as possible.